



**A600-1GLP, A600-1GN, A600-1O
110V and 220V
INCINERATOR
Installation and Operators Manual**



Agile Manufacturing
720 Industrial Park Road
Anderson, MO 64831
Ph: 800-704-7356
Fax. 417-845-6069
www.shenmfg.com
www.agilemfg.net

WARRANTY WARNING

- 1. Tampering with orifices in the burner will void warranty.**
- 2. Failure to cure refractory before using will void warranty.**

CONTENTS

| | |
|--|-----------|
| LIMITED WARRANTY | 3 |
| WARRANTY | 3 |
| LIMITATIONS | 3 |
| A600 INCINERATOR SPECIFICATIONS | 5 |
| A600 PACKING LIST | 7 |
| SITE INFORMATION | 8 |
| PLACEMENT AND CONSTRUCTION RECOMMENDATIONS | 8 |
| ELECTRICAL SERVICE | 8 |
| FUEL SUPPLY | 9 |
| NAT GAS AND LP | 9 |
| FUEL OIL | 10 |
| COMBUSTIBLE ROOF CONSTRUCTION | 11 |
| ASSEMBLY INSTRUCTIONS | 12 |
| BURNER SETTINGS & AIR ADJUSTMENTS | 13 |
| GAS PRESSURE ADJUSTMENTS | 15 |
| OPERATING INSTRUCTIONS | 16 |
| REFRACTORY CURING PROCEDURE | 16 |
| TROUBLE SHOOTING | 17 |
| NAT GAS & LP MODELS | 17 |
| FUEL OIL MODELS | 17 |
| A600 PARTS LIST | 18 |
| MIDCO BURNER (J121-DS) EXPLODED VIEW | 19 |
| BECKETT BURNER (SF) EXPLODED VIEW | 21 |

LIMITED WARRANTY

Warranty

Agile Manufacturing, a division of CTB, Inc., WARRANTOR, warrants to the original purchaser for a period of one (1) year from date of purchase or delivery to original purchase, products manufactured by it which are installed and operated according to WARRANTY'S instructions that are furnished and/or are available to purchaser upon request, and installed according to other applicable Federal, State, and local codes or regulations and upon substantiation that said products were installed correctly, were not abused, and or defective. The exact nature of said warranty and exclusive remedy for breach of warrantor is as follows:

WARRANTOR will refund or credit to purchaser's account an amount equal to the original purchase price or at WARRANTOR'S option repair or replace at WARRANTOR'S expense products found to be defective in workmanship or material. If a problem occurs which the purchaser believes is covered by this warranty, then purchaser shall contact the seller giving the seller sufficient information to enable a resolution to the problem. If the seller is unable or unwilling to resolve the problem and purchaser is still convinced that it is covered by the warranty the purchaser should contact the manufacturer at the address listed in the following paragraph and provide a description in writing of the problem and the attempts made to resolved it. "Seller" as used herein shall mean the dealer or distributor from whom the product was purchased.

No product or part thereof may be returned pursuant to this warranty without first receiving specific written permission to do so. All request should be addressed to Agile Manufacturing at 720 Industrial Park Road Anderson, MO 64831 requesting specific authority for returning merchandise pursuant to this warranty with reasons for the request.

Limitations

Products which are abused or neglected are not covered under this Warranty. WARRANTOR shall not be responsible for the costs of removal or reinstallation of its products and shall not be liable for transportation costs to and from it factory. Further, WARRANTOR shall not be liable for replacement, repair, or refund for component parts not manufactured by it.

Use of parts for modification or repair of the unit or any component not authorized or manufactured by Agile Manufacturing, specifically for this product shall void this warranty.

IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE SAME PERIOD OF TIME AS THIS EXPRESS LIMITED ONE (1) YEAR WARRANTY AND ARE SPECIFICALLY DISCLAIMED THEREAFTER.

AGILE MANUFACTURING, SHALL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, OR CONTINGENT DAMAGES OR EXPENSES ARISING DIRECTLY OR INDIRECTLY FROM ANY DEFECT IN THE PRODUCT HEREBY WARRANTED.

THIS WARRANTY SHALL BE **VOID** IF SOLVENTS OR OTHER HIGHLY INFLAMMABLE FLUIDS, SUCH AS BUT NOT LIMITED TO, BENZENE, METHYLETHYL, KETONES, TOLUENE, XYLENE, OR NAPHTHA ARE BURNED IN OR MIXED WITH OIL FOR BURNING IN USED OIL-FIRED BURNING HEATERS OR FURNACES.

For those states that do not allow limitations on how long an implied warranty lasts, this limitation may not apply. Similarly, for those states that do not allow the exclusion on limitations of incidental or consequential damages, the above exclusions of indirect, incidental, or consequential damages may not apply.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Agile Manufacturing is not responsible for any undertaking, representation, or warranty made by dealer, distributor, or other persons, beyond those expressly set forth in this warranty.

WARRANTY WARNINGS

WARRANTY WARNING

- 1. Tampering with orifices in the burner will void warranty.**
- 2. Failure to cure refractory before using will void warranty.**

A600 INCINERATOR SPECIFICATIONS

Table 1: WASTE CHAMBER

| | |
|---------------------------|----------------------------------|
| CHAMBLER CAPACITY: | 600 lbs. Type IV waste (poultry) |
| CHAMBER VOLUME: | 18.9 cubic feet |
| DOOR DIMENSION: | 26" x 30" |
| HEIGHT TO DOOR: | 32.75" |
| REFRATORY: | 3", 2800°f, 126 lbs/cubic feet |
| JACKET MATERIAL: | 14 gauge aluminized steel |
| HEIGHT TO TOP OF CHAMBER: | 34" |

Table 2: STACK

| | |
|---------------|-------------------------------------|
| DIMINENSIONS: | (2) 12" Dia., 60" L |
| JACKET: | SS 304-2B 16 GA |
| STACK CAP: | SS 304-2B: 18 GA (12" Dia. X 14" H) |

Table 3: BURNER

| | |
|-----------------------|---|
| MODEL: NAT GAS and LP | One (1) Midco 121-DS Direct Main Flame Spark Ignition Electronic Flame Safety, 100% Shut-offs, 1,200,000 BTUH (maximum) |
| MODEL: OIL | One (1) Beckett SF Oil Burner W/ Flame Safety, 390,000 BTUH |
| OPERATION: | One (1) 12 Hour Manual Timer |

Table 4: GENERAL

| | |
|---|---|
| EXTERNAL DIMENSIONS: | 36" W x 34" H x 60" L (less stack). |
| OVERALL DIMENSIONS (APPROX.), INCLUDING COUNTERBALANCE WEIGHTS, BURNER, STACK AND STACK CAP | 56" W x 213" H x 75" L |
| ELECTRICAL SERVICE: | Standard-110 volt, 60hz, 20 amp, Also available -- 220 volts, 50hz, 10 amp |
| GAS SERVICE: | 530,000 BTUH (piping sized accordingly) Natural Gas: 7" W.C. (with burner operating) Liquid Propane: 11" W.C. (with burner operating) |
| GAS/FUEL CONSUMPTION: | Natural Gas = 530 CFH Liquid Propane = 5.8 GPH Fuel Oil = 3.0 GPH |
| TOTAL WEIGHT: | lbs (approx) |
| PAD REQUIREMENTS: | 12' W x 14' L x 4" D (if sheltered) 8' W x 10' L x 4" D (if not sheltered) |
| PAINT: | 1200 degree primer 1200 degree paint |

Table 5: CHARGING RATE

| | |
|---------------|---|
| PATHOLOGICAL: | Up to 600 lbs. per charge of typical pathological waste with a BTU/lb rating of 1000. Batch loaded allowing complete burn-out 6-8 hours, cool down and ash removal before reloading |
| BURN RATE: | Approx. 75lb./hr. |

Must be installed in accordance with local codes and ordinances, subject to regulatory agencies. Stack test data is available from the distributor for permit application. If on-site testing is required, it is the responsibility of the purchaser and can be arranged through the distributor. Outside installation is recommended with a simple metal roof or three-sided metal shelter, provided a **minimum** of four (4) foot clearance from any combustible material. Inside installations may have special insurance requirements. Factory must be advised.

A600 PACKING LIST

Primary Chamber Components

| | |
|---|--|
| 1 | Primary Chamber w/ top & door assembly |
| 2 | Counter Weight Arms |
| 8 | Counter Weights |

Chamber & Stack Hardware

| | |
|----|------------------------------|
| 16 | 3/8 - 16 x 3/4 bolts |
| 16 | 3/8 - 16 nuts |
| 4 | 5/16 - 18 nuts |
| 4 | 5/16 - 18 x 9 bolts |
| 8 | 5/16ID X 2"OD fender washers |
| 1 | Latch |

Stack Components

| | |
|---|-----------------------------------|
| 1 | 5' SS Stack section |
| 1 | 5' SS Stack Extension |
| 1 | 2' refractory lined stack section |
| 1 | Stack cap |

Burner & Hardware

| | |
|---|--|
| 1 | Burner Midco J121-DS or Beckett SF |
| 1 | Burner cover |
| 1 | 3/4" Gas cut off valve (NAT Gas and LP only) |
| 1 | Pressure gauge (NAT Gas and LP only) |
| 1 | Oil filter (oil burner only) |
| 4 | 1/4 - 20 X 1/2 bolts (oil burner only) |
| 4 | 1/4 - 20 nuts (oil burner only) |
| 2 | Brass flare ell (oil burner only) |
| 1 | Brass flare fitting (oil burner only) |
| 2 | Brass flare nut (oil burner only) |
| 1 | 1/4 x 3/8 bushing (oil burner only) |
| 1 | 1/2 x 3/8 bushing (oil burner only) |
| 1 | 3/8 x 2 pipe nipple (oil burner only) |

SITE INFORMATION

Placement and Construction Recommendations

- The A600 incinerator is designed for outdoor installation on a concrete slab 6' x 8' x 4" thick. (12' x 14' x 4" if sheltered)
- The A600 may be installed in a three sided shelter, but must comply with local building and fire codes for clearances from combustible walls and materials. A minimum clearance of 4' around the incinerator is recommended for service and maintenance.
- For recommended construction of a metal chimney through a combustible roof, **See Figure 3: "Combustible Roof Construction Diagram" on page 11**

Electrical Service

115 volts, 60hz, 20 amp for NAT Gas, LP, & Fuel Oil

- Electrical service can be supplied by plugging into the cord set.

NOTE: Polarity must be maintained or the burners will not operate. If burners "lock out" after approximately 5 seconds and the blower continues to operate, then the polarity is incorrect. It should be corrected at the power source, not in the incinerator control.

220 volts, 50hz, 10 amp for NAT Gas & LP

- Electrical service can be supplied through the electrical cord at the burner by adding the type of plug that will fit your application.

220 volts, 50hz, 10 amp Fuel Oil only

1. Loosen the (2) screws and swing open the transformer.
2. Make wire connections as follows:

| <u>Electrical Service</u> | <u>Connections at Transformer</u> |
|---------------------------|-----------------------------------|
| L1 | Black wire with wire nut |
| L2 | White wire with wire nut |

3. Close transformer and tighten screws.
4. Connect the electrical cord from the burner to the timer as follows:

| <u>Electrical Cord</u> | <u>Timer terminal</u> |
|------------------------|-----------------------|
| Black wire | L1 |
| White wire | T1 |



Fuel Supply

NAT Gas and LP

PIPING:


1. Install gas train with 3/4" minimum dia. pipe or tubing. Larger pipe may be needed depending on the gas supply and regulator location. The A600-1G requires 530,000 BTUH for operation.
2. Using soap solution, leak test all gas connections.

REGULATOR:

1. Use a properly sized regulator which maintains reduced pressure under static conditions when no gas is flowing. (Dead end lock up).
2. For best results install regulator as near as possible to the incinerator.
3. Regulate LP gas to 11" W.C., NAT gas to 7" W.C. (while burner is burning).
4. Do not exceed 14" W.C. under static conditions when there is no gas flow.

PRESSURE GAUGE:

- A gas pressure gauge is supplied with each incinerator and should be located between the regulator and gas shut off valve, as close to the burner as possible. See below.



FUEL SUPPLY (CONTINUED)


Fuel Oil

OIL TANK:

1. Since tanks vary in size and fixtures, you may need to make adaptations to use the parts supplied.
2. It is important that a filter be provided in the line between that tank and the incinerator.
3. If the flow outlet is on the underside of the tank, extend a threaded nipple about 2" into the tank to avoid problems from condensation in the bottom of the tank.

PIPING:


1. A flaring tool will be needed to form the ends of the copper tubing.
2. Assemble 3/8" copper tubing, oil filter, shut-off valve and fittings between the oil tank and the burner.



COMBUSTIBLE ROOF CONSTRUCTION

RECOMMENDED CONSTRUCTION FOR METAL CHIMNEY THROUGH COMBUSTIBLE ROOF


- 1. DIMENSIONS ARE MINIMUM DISTANCES
- 2. BASED ON NFPA 82
- 3. CONSULT LOCAL BUILDING CODES
- 4. STOCK SHOULD EXTEND NOT LESS THAN 10 FT. HIGHER THAN ANY BUILDING WITHIN 25 FT.



ASSEMBLY INSTRUCTIONS

1. Position the incinerator on the concrete slab as needed for fuel and electrical hook up.
2. Bolt the 5' stainless steel stack to the 2' refractory lined stack using (8) 3/8 – 16 x 3/4 flange bolts and (8) 3/8 – 16 flange nuts.
3. Slide the 5' stainless stack over the 5' ss stack below.
4. Position the stack cap over the top of the stack and secure with (3) #10 X 1/2 sheet metal screws.
5. Bolt the toggle clamp to the primary chamber at the mount bracket using (4) 3/8-16x3/4 flange bolts and (4) 3/8-16 flange nuts.
6. Attached the counter weight arms to the door arms using (6) 3/8-16x3/4 flange bolts and (6) 3/8-16 flange nuts.
7. Bolt the counter weights to the counter weight arms (be sure door is clamped closed) with (4) 5/16-18 x 9 bolts, (4) 5/16 - 18 Nylock nuts and (8) 5/16 X 2 washers.
8. Attach the burner and housing as described below.
 - a. For Nat Gas & LP burners - Attach the burner cover and burner to the primary chamber with (4) 3/8-16 flange nuts.
 - b. For Fuel Oil Burners -
 1. Make sure that the flange on the burner tube is about 5 3/4" from the burner housing.
 2. Attach the burner cover to the bracket on the burner with (4) 1/4 - 20 X 1/2 bolts and nuts.
 3. Attach the burner to the primary chamber with (4) 3/8-16 flange nuts.

NOTE: FOR BEST BURN
MAINTAIN 3.50" BETWEEN
BURNER HOUSING AND FLANGE



BURNER SETTINGS & AIR ADJUSTMENTS

Table 1: Midco J121-DS Burner

| FUEL | AIR SHUTTER | PILOT ORIFICE | ORIFICE | BTUH |
|------|-------------|---------------|---------|---------|
| LP | Open* | #58 | 9/32 | 530,000 |
| NAT. | Open* | #55 | 25/64 | 530,000 |

*The air shutter is adjusted to the FULL OPEN position from the factory and should never be moved.





Figure 1: Air Shutter (Midco burner)

BURNER SETTINGS & AIR ADJUSTMENTS (continued)

Table 2: Beckett SF Burner

| FUEL | AIR SHUTTER | AIR BAND | NOZZLE | RETENTION HEAD | BTUH |
|----------------------|-------------|----------|-------------------------|----------------|---------|
| #2 Fuel Oil (Diesel) | Closed ** | #8 ** | 3.0 GPH 30 degrees A | F31 | 390,000 |

**These openings are approximate. Final adjustments may be necessary at installation.



Air Band indicator
(Beckett burner)



Air Shutter indicator
(Beckett burner)

GAS PRESSURE ADJUSTMENTS

(for NAT Gas and LP only)

***PROPER GAS PRESSURE IS CRITICAL TO THE OPERATION OF THE INCINERATOR**

Gas pressure must be adjusted when the burner is operating and set as follows:

Note: A gas pressure gauge is supplied with each incinerator (NAT Gas and LP only).

Nat Gas = 7" W.C.

L.P. Gas = 11" W.C.

OPERATING INSTRUCTIONS

Curing of the refractory is essential prior to burning the first load of waste. See "REFRACTORY CURING PROCEDURE" below.

1. Remove ashes before loading the incinerator.
2. Load incinerator. Keep the waste 6"-8" away from the burner port.
3. Start burner by setting the timer for the desired burn time. A full load will normally burn out in 6-8 hours.
4. The incinerator will automatically shut off when the burn is completed.
5. For best results, burn daily to a white ash.

REFRACTORY CURING PROCEDURE

Table 1: REFRACTORY CURING PROCEDURE

| Procedure | Time |
|---------------------------|-----------------------|
| Start burner and burn for | 5 minutes |
| Allow to cool for | 15 minutes |
| burn | 5 minutes |
| cool | 15 minutes |
| burn | 15 minutes |
| cool | 15 minutes |
| burn | 15 minutes |
| cool | 15 minutes |
| burn | 30 minutes |
| cool | 15 minutes |
| burn | 30 minutes |
| cool | 15 minutes |
| burn | 1 hour |
| cool | 15 minutes |
| burn | 1 hour |
| cool | 15 minutes |
| burn | 1 hour |
| cool | 15 minutes |
| burn | 2 hour |
| cool | 15 minutes |
| burn | 3 hours |
| Total Time | 12 hours(approximate) |

There will be hairline cracks and minor scaling of the refractory when curing is complete. This is a normal result of the curing process.

TROUBLE SHOOTING

Nat Gas & LP Models

No spark at electrodes

1. Is burner blower operating? Possible defective blower motor.
2. Clean electrodes and pilot igniter assembly. Apply heat if moisture is present.
3. Check electrode position. See drawing in Midco manual for proper adjustment.
4. Defective Honeywell Control Board. Check voltage to 25V terminal on board.
5. Check service breaker, timer, electrical connections, and polarity.

Spark but no ignition

1. Confirm gas pressure. LP gas @ 11" WC or NAT gas @ 7" WC.
2. Clean electrodes and pilot igniter assembly. Apply heat if moisture is present.
3. Check electrode position. See drawing in Midco manual for proper adjustment.
4. Listen to confirm that solenoid gas valve is opening. Possible defective gas valve.
5. Check for dirt in brass pilot orifice tee.

If incinerator does not burn properly

1. Have the ashes been removed at the beginning of the day?
2. Be sure there is no obstruction blocking the burner tube.
3. Is the air shutter in the full open position? See diagram in "BURNER SETTINGS" section of this manual.
4. Check gas pressure while the burner is burning. LP gas @ 11" WC or NAT gas @ 7" WC.

Fuel Oil Models

No spark at electrodes

1. Be sure there is no obstruction in the end of the burner tube and there is no soot build-up on the retention head, electrodes or nozzle.
2. Check all electrical connections.
3. Transformer may be burned out. Listen or look to see if there is an arc across the electrodes. Replace transformer if no spark is present.
4. Check for damage to electrodes.
5. Improper firing head adjustment. See Beckett burner installation manual.

No oil spray through nozzle

1. Defective motor. Check to see if blower wheel is turning. If not, check electrical connections and voltage to motor.
2. Air in fuel line. Check all fittings between burners and at fuel tank for tightness. Air may be bled from the fuel line at the fuel pump.
3. Dirt or water in oil tank.
4. Check the plastic coupling between motor and pump for tight fit.
5. Check for clogged filter at tank or on nozzle.
6. Be sure there are no kinks in the oil line.
7. Check the tubing between the pump and nozzle for blockage.
8. Defective pump.

If incinerator does not burn properly


1. Have the ashes been removed at the beginning of the day?
2. Be sure there is no obstruction blocking the burner tube.
3. Are the air bands adjusted correctly? (See "BURNER SETTINGS" section in this manual).
4. Is No. 1 Fuel Oil (Kerosene) or No. 2 Fuel Oil (Diesel) being used as fuel?

A600 PARTS LIST


Table 1.A600-1 Parts

| Parts not shown | |
|---------------------|--|
| 103356 | Natural Gas Burner 110V |
| 103355 | LP Burner 110V |
| 23041 | Fuel Oil Burner 110V |
| 31553 | Natural Gas Burner 220V |
| 31552 | LP Burner 220V |
| 23043 | Fuel Oil Burner 220V |
| 103610 | Main Chamber complete w/ top and door |
| Miscellaneous parts | |
| 56917 | Door Gasket (Fiberglass Rope,142") |
| 32053 | 12 Hour Timer/Switch (gas & oil burners) |
| 35024 | Gas Pressure Gauge, 0-35" WC |
| 34034 | 2-1/2 Lbs. Mastic Cement in Pint Can |
| 34035 | Refractory Cement (50 lb. bag) |
| 102665 | 20 Lbs. Mastic Cement in Gallon Can |
| 32301 | Metallic Brown Spray Paint (can) |

| Key | Part Number | Description |
|-----|-----------------|--|
| A | 86230 | Stack Cap (Stainless Steel) |
| B | 31510 | Stack Extension, 5' x 12" dia. (Stainless Steel) |
| C | 31535 | Stack, 5' x 12" (Stainless Steel) |
| D | 77602 | Load Door |
| E | 101030 | Door Clamp |
| F | 77600 | Burn Chamber Top Only |
| G | 77605 | Ash Door |
| H | 77601 | Lower Burn Chamber Less Top |
| J | 77603 | Arm, Door Mount |
| K | 77604 | Arm, Weight Mount |
| M | 31599 | Counter Balance Weight |
| N | 100725 20337 | Housing, Gas & LP Burner Housing, Oil burner |
| P | 32624 | Stack, 2' x 14" diameter, Refractory Lined |



MIDCO BURNER (J121-DS) EXPLODED VIEW




See parts list on following page.

PARTS LIST: MIDCO burner (J121-DS)

| Key | Part Number | Description |
|-----------|-------------|---|
| A | 33116 | Manifold |
| C | 31603 | Flange Gasket |
| D | 33125 | Blower Wheel |
| G | 33140 | Ground Barrier Kit |
| H | 33113 | Main Gas Port and Tube Kit – PROPANE |
| I | 31581 | Main Gas Port and Tube Kit – NATURAL |
| J | 33129 | Transformer 115/1/50-60 Primary, 24V-30VA Or |
| | 101420 | Transformer 220/24V 50/60 Hz, 35VA |
| K | 33109 | 3/4" NPT Gas Valve -- 24 Volt |
| L | 33121 | Electrode (spark or flame) - 2 required |
| M | 33138 | Electrode Wires, Boots and Strain Reliefs |
| N | 33131 | Ignitor Assembly |
| O | 33126 | Motor, 115/1/50-60 Hz Or |
| | 101426 | Motor, 220/1/60 Hz |
| P | 33112 | Ignitor Regulator 1/8 NPT |
| Q | 33120 | Thermal Switch |
| R | 33151 | DSI Electronic Control Board |
| S | 33118 | Input Adjuster Sealing Gasket |
| Not Shown | 33136 | PROPANE Conversion Kit |
| Not Shown | 33135 | NATURAL Conversion Kit |

BECKETT BURNER (SF) EXPLODED VIEW



See parts list on following page.

PARTS LIST: BECKETT BURNER (SF)

| Item | Part Number | Description |
|-------------|--------------------|--|
| A | 101271 101266 | Ignition Transformer 120v/60hz Ignition Transformer 220v/50hz |
| B | 101273 101268 | Primary Safety Control 120v/60hz Primary Safety Control 220v/50hz |
| C | 101269 | Flame Detector |
| D | 101270 101262 | SF Burner Motor 120v/60hz AF Burner Motor 220v/50hz |
| E | 101265 | Blower Wheel |
| F | 101263 | Flexible Coupling |
| G | 101264 | Fuel Pump |
| Not Shown | 101272 | Solenoid Valve 120v/60hz |
| Not Shown | 101267 | Solenoid Valve 220v/50hz |
| Not Shown | 101332 | F310 Retention Head |
| Not Shown | 101472 | Connector Tube Assembly |
| Not Shown | 101471 | Air Tube Assembly |
| Not Shown | 101473 | Nozzle Line Electrode Assembly |
| Not Shown | 101474 | Electrode |
| Not Shown | 22137 | Nozzle: 2.50 x 30A |